

nuance audio


Shortcuts and on frame interactions

How do you activate shortcuts?




Go to **Menu** > **Shortcuts** > toggle the switch on "**Double tap**" and "**Change presets**".






Shortcuts on the frame
Listening Assistance


Switch Audio mode
Double tap (Opt-in).



Preset up
Press (**+**) and hold 1.25 seconds (Opt-in).




Preset down
Press (**-**) and hold 1.25 seconds (Opt-in).




Shortcuts on the frame
Calls

Answer
Double tap (Opt-in).




End
Double tap (Opt-in).




On frame interactions
General


Power on
Slide on



Power off
Slide off




Force shutdown
Slide off then press (-) and hold 12 seconds.




On frame interactions
General

1st Pair
Slide on




2nd Pair
Press (**+**) or (**-**) and hold for 8 seconds.




On frame interactions
General

Exit
Slide off



Factory reset
Press (+) and (-) and hold both 10 seconds.



On frame interactions
General

Sleep
Fold




Wake up
Unfold




On frame interactions
Volume

Volume up
Press (+)



Volume down
Press (-)



nuance audio

in tune with life

For the most updated Instructions for Use please follow this link

↗ View instruction for use